

90cm Gas Slimline Cooktop

COOKTOP

PRODUCT CODE: **E90CTWX**



FEATURES:

- + Stainless steel finish
- + 5 gas burners includes triple ring wok burner
- + Front control knobs
- + One piece hob for ideal cleaning
- + Automatic ignition
- + Cast iron pan supports
- + Flame failure safety device
- + Natural gas or LPG (jets included)
- + Stylish flat slim line design
- + Made in Italy

IDEAL CLEANING

Cook top surface all in a "one piece hob setting" which makes cleaning the cooktop a simple, non-time consuming activity.

ONE TOUCH ELECTRONIC IGNITION

This gas cooktop uses a one touch electronic ignition system. Simply push down the knob and turn and the flame will ignite automatically.

CAST IRON TRIVETS

Non-slip, cast iron trivets are standard with this cooktop and removable for easy cleaning.

FLAME FAILURE SAFETY DEVICE

The flame failure device is a safety mechanism which ensures the gas is automatically turned off in the case of the flame extinguishing.

SPECIFICATIONS:

| | |
|--|--|
| Electrical Requirements | Cooktop is supplied with 10 amp plug & cord. |
| Gas Rated Pressure: | |
| - LPG | 2.75 kPa |
| - Natural | 1.00 kPa |
| Gas Burners: | |
| - Wok Burner (Left) | 13.0 MJ/h |
| - Auxiliary Burner (Front Centre) | 3.40 MJ/h |
| - Rapid Burner (Rear Right) | 11.5 MJ/h |
| - Semi Rapid Burners (Front Right + Rear Centre) | 6.30 MJ/h |
| Weight | 13.5 kg net / 11.5 kg gross |
| Product Dimensions | W890mm x D510mm |



eurocooking



Warranty

CLEANING AND MAINTENANCE

- + Cleaning operations must only be carried out when the appliance is completely cool.
- + Clean the appliance regularly, preferably after each use
- + Abrasive cleaners or sharp objects will damage the appliance surface; you should clean it using water and a little washing liquid

SAFETY INFORMATION

- + Do not use this appliance if it comes in contact with water. Do not operate this appliance with wet hands.
- + The heating and cooking surfaces of the appliances become hot when in use, take all due precautions.
- + Unstable pans should not be used on the appliances as they can cause an accident by tipping or spillage.
- + Never leave the appliance unattended when cooking.
- + Please refer to the manual for more information.

INSTALLATION DIAGRAM

