LAMP. HES INSTALLATION MANUAL FOR HES3D-E160 CONCEALED HINGE

Thank you for using our product. Before installation, please read this manual thoroughly to ensure correct installation. Please keep this manual at hand for future reference.

ABOUT THE PRODUCT

- This product is a concealed hinge for indoor use, that is recessed into the door and doorframe.
- Three dimentional adjustment function allows vertical, horizontal, and depth adjustment.

DOOR SPECIFICATION

Min. Door thickness	36 mm
Max. Door weight	55 kg per 2 hinges, 70 kg per 3 hinges
Max. Door size	Width: 900 mm, Height: 2400 mm

FOR YOUR SAFETY AND CORRECT INSTALLATION

Meaning of symbols

Warning Caution



COMPONENT PARTS (PER BOX)

- Concealed hinge
- Screw cover
- Template
- 4 pcs×2 bags 1 pc


2 pcs

- Countersunk head tapping screw 5×25
 - 8 pcsimes2 bags
- Hex Key 4mm
- 1 pc


🕂 Caution: If not followed, injury or damage may result.

- Provide a frame that can withstand the weight and impact of opening and closing the door. Be sure to use the specified screws and tighten them securely. If the mounting strength is insufficient, the door may fall and cause injury.
- \bigotimes Do not use this product for any other purpose, or with doors that are outside the specifications of this manual.
- Use in conjunction with a door closer is not recommended. For soft-close option, we recommend Sugatsune LDD-V or LDD-S door damper.
- Follow the specified dimensions, specifications, and alignment of the door and frame. Warping, tilting or twisting of the frame or door may cause failure.
- This product is a part for architectural fittings. After installation, please check the function and safety of the final product. Please inform the end user how to use the product safely.
- Make sure to check the screws for slack at regular intervals (one month from first usage, half a year, and then one time every year is recommended).

INSTALLATION DRAWING (EXAMPLE)




CUT OUT DRAWING FOR DOOR AND DOORJAMB




INSTALLATION PROCEDURE


1 Disassembly of Hinge Screw cover Screw cover

2 Installing Hinge to Door and Doorframe





4 Fastening the Hinges



ADJUSTING DOOR POSITION

3 Hanging Door

Door

The arrows should point in the direction of adjustment when the door is closed.


Door frame

doorframe

While holding the door, insert the hinge main body into the base frame on the

Keep holding the door

and fix the hinge with the fastening screws at once.



ISO9001(Japan Offices and Sugatsune America) and ISO14001(Chiba Production division and Logistics center), certified.

2021.07 1317-3